



Benefits & Features

Veritas Global Essentials Plans

✓ Emergency Roadside Assistance

We pay for the cost of emergency roadside services, including:

- Towing
- Battery Jumpstarts
- Flat Tire Changes
- Lockout Assistance
- Fuel Delivery (You are responsible for fuel costs)

✓ Rental Car Coverage

We pay for the expense of a rental car when your vehicle's failure is approved for repair.

✓ Trip Interruption Benefits

In the event you experience a breakdown 100 miles away from your home, we will pay for a portion of your meals and lodging for covered repairs.

✓ Nationwide Protection

All of our plans can be used nationwide, so if you are traveling and experience a breakdown, you can rest assured your plan will be accepted.

✓ Transferable Coverage

If you sell your car, you can transfer the coverage to the new owner, which increases the value of your vehicle!

** Please view each contract for full details on coverage of each plan.*



Costs *WITHOUT* Veritas

Engine \$7,349	A/C Repair \$1,232	Transmission \$3,911
Drive Axle \$1,508	Front End Repair \$901	

Cars have problems.

Everyone has insurance on their vehicles to protect them in the event of an accident. However, many people who have collision insurance never use it. On the other hand, nearly every vehicle will require repairs due to mechanical failure. An average engine costs **\$7,349** to repair and the average transmission costs **\$3,911**. While these represent the major components, minor parts can still cost anywhere from **\$300** to **\$3,000**.

The question you need to ask is simple: **do you want to pay for these huge repair costs or would you rather someone else pay it for you?** With a Veritas vehicle protection plan, we pay the costs so you don't have to. In many situations, the cost of a single covered repair pays for the entire protection plan!

A mechanical breakdown can be very stressful, not only costing you money, but time. This is why **all our protection plans come with emergency roadside assistance, first day rental car benefits, and travel interruption coverage included at no extra cost.**

With a **Veritas protection plan**, you have someone to call if you are ever stranded due to a breakdown. We will put you in a rental car and most importantly, cover the cost of your repairs to get you back on the road. We provide you with peace of mind, knowing your vehicle is covered by a company backed by an "A" rated insurer, accredited by the Better Business Bureau, and a reputation for providing the best customer service in the industry.

All of our protection plans are accepted at any ASE certified dealership or mechanic in the United States.

**Please see your contract for details*

ADMINISTRATOR:

Veritas Global Protection Services, INC

3550 North Central Avenue Suite 800
Phoenix, AZ 85012

(888) 572-4310 | www.veritasprotection.com



Veritas

Global Protection

ESSENTIALS PLANS



Peace of Mind, Worldwide
veritasprotection.com/essentials

Essentials PLANS

Levels of Coverage.

Our Veritas Global Essentials Program is designed to give you peace of mind right after you make a purchase. Our Essentials Program is available in both short and long-term contracts, ranging from 3 months to 5 years. All of our Essentials plans cover the most important parts of your vehicle that are at the highest risk of breakdown.



Powertrain

This plan covers the most important components on your vehicle including the Engine, Turbo/Supercharger, Transmission, Transfer Case, Drive Axle.



Powertrain Plus

Covers all of the Veritas Global Essentials Powertrain components plus additional important components such as Electrical Components, Air Conditioning Components.



Powertrain Enhanced

This level of coverage includes all the components from Powertrain & Powertrain Plus along with an enhanced list of components from already covered systems.

All coverage options come with free 24 hour roadside assistance, towing, and a rental car program.



Compare Coverage Levels →

Refer to our comparison chart on right to find the best Veritas Global Essentials Plan for your vehicle.

engine (gas or diesel)

Pistons, Piston Rings, Crankshaft and Main Bearings, Connecting Rods and Rod Bearings, Camshaft and Camshaft Bearings, Timing Chain and Timing Gears, Intake and Exhaust Valves, Valve Springs, Oil Pump, Push Rods, Rocker Arms, Hydraulic Lifters, Rocker Arm Shafts and Water Pump. The Engine Block and/or Cylinder Heads are covered only if caused by the failure of a covered component.

transmission / transaxle

All internally lubricated parts of the Automatic or Manual Transmission, including Oil Pump, Drums, Planetaries, Sun Gear and Shell, Shafts, Bearings, Side Gears, Carrier Pinion Gear, Ring Gear, Shift Rail, Forks, Synchronizer, and Torque Converter. Breakdown of the Transmission/Transaxle Case is covered only if caused by the failure of an internally covered lubricated component.

transfer case

All internally lubricated parts of the 4 x 4 transfer case. The Transfer Case is covered only if damage is caused by the failure of a covered internally lubricated part.

drive axles

All internally lubricated parts. Drive Axle housing is covered only if damage is caused by the failure of a covered internally lubricated part.

turbo / supercharger (factory only)

All internally lubricated parts of the factory installed turbo/supercharger. The turbo/supercharger housing is covered only if damage is caused by the failure of a covered internally lubricated part.

air conditioning

Condenser, Compressor, and Evaporator. Orifice Tube and Accumulator/Receiver Dryer are covered only if damage is caused by the failure of a covered part.

cooling system

Cooling Fan, Cooling Fan Motors, and Cooling Fan Clutch.

fuel system

Fuel Pump, Fuel Injection Pump, Metal Fuel Lines, Fuel Pressure Regulator, Fuel Sending Unit, and Fuel Gauge.

electrical

Alternator, Voltage Regulator, Heater Fan, Starter Motor Starter Solenoid, and Starter Drive.

enhanced electrical

Power Window Motors and Regulator, Power Door Lock Actuators, Power Trunk Switch, and Power Antenna Motor.

seals and gaskets

Seals and gaskets are covered in connection with the replacement or repair of a covered part.

